


Eijlander Electronics b.v.

LUIDSPREKERKABELS:

LUIDSPREKERKABEL 2-ADERIG

SPEAKON → SPEAKON


PIN 1+ → PIN 1+: + HEET
PIN 1- → PIN 1-: - MASSA
PIN 2+ → N.C.
PIN 2- → N.C.



LUIDSPREKERKABEL 4-ADERIG

SPEAKON → SPEAKON

PIN 1+ → PIN 1+: + HEET KANAAL 1 TOP
PIN 1- → PIN 1-: - MASSA KANAAL 1 TOP
PIN 2+ → PIN 2+: + HEET KANAAL 2 SUB
PIN 2- → PIN 2-: + MASSA KANAAL 2 SUB



LUIDSPREKERKABEL 4-ADERIG

EP 4-POLIG → EP 4-POLIG


PIN 1 → PIN 1: + HEET KANAAL 1 TOP
PIN 2 → PIN 2: - MASSA KANAAL 1 TOP
PIN 3 → PIN 3: + HEET KANAAL 2 SUB
PIN 4 → PIN 4: - MASSA KANAAL 2 SUB



LUIDSPREKERKABEL 8-ADERIG

EP 8-POLIG → EP 8-POLIG


PIN 1 → PIN 1: + HEET KANAAL 1
PIN 2 → PIN 2: - MASSA KANAAL 1
PIN 3 → PIN 3: + HEET KANAAL 2
PIN 4 → PIN 4: - MASSA KANAAL 2
PIN 5 → PIN 5: + HEET KANAAL 3
PIN 6 → PIN 6: - MASSA KANAAL 3
PIN 7 → PIN 7: + HEET KANAAL 4
PIN 8 → PIN 8: - MASSA KANAAL 4



LUIDSPREKERKABEL 2-ADERIG

XLR → XLR


PIN 1 → PIN 1: - MASSA
PIN 2 → PIN 2: + HEET
PIN 3 → N.C.



LUIDSPREKER - ADAPTERKABEL 2-ADERIG

XLR → SPEAKON

PIN 1 → 1-: - MASSA
PIN 2 → 1+: + HEET
PIN 3 → N.C.



LUIDSPREKER - ADAPTERKABEL 2-ADERIG

XLR → JACK MONO

PIN 1 → JACK HUIS: - MASSA
PIN 2 → JACK PUNT: + HEET
PIN 3 → N.C.

